

Instructions for mounting the A522 Bracket for 2005-2005 model Dodge Caravans

Step 1: Remove dash panel

Step 2: Remove steel knee bolster

Step 3: Disconnect airbag plug and install the shunt. Instructions for installing the shunt are provided in the bag

Step 4: Locate the two studs that hold the steering column to the frame. Remove the nut and place the bracket on the stud. Replace the OEM nuts on the studs and tighten to 25ft/lbs.

When the bracket is installed it should look like this:



Here is a picture of the bracket with the support rod coming out of the dash.



You can now proceed with the installation from section 9.4 in your Sure Grip installation manual.