Instructions for Mounting Sure Grip Hand Controls into 2001-2004 Model Dodge Caravans

The bracket for the 2001-2004 model Caravans is the same as the bracket for the 1996-2000 Caravans but with one small change. Instead of having three holes that align with three OEM studs, the A521 has two holes that align with OEM studs and a self threading screw for extra support. The picture below is of an A520 bracket (for the previous generation) with an arrow indicating where the installer must put the screw